

## STAS GARNITURI

Diametrul nominal	Diametrul interior	Diametrul exterior al garniturilor pentru flanse plate etansare PU conform DIN 2690							
		PN 2,5	PN 6	PN 10	PN 16	PN 25	PN 40	PN 64	PN 100
DN	d	D							
10	18	38	38	45	45	45	45	56	56
15	22	43	43	50	50	50	50	61	61
20	28	53	53	60	60	60	60	72	72
25	35	63	63	70	70	70	70	82	82
32	43	75	75	82	82	82	82	88	88
40	49	85	85	92	92	92	92	103	103
50	61	95	95	107	107	107	107	113	120
65	77	115	115	127	127	127	127	138	145
80	90	132	132	142	142	142	142	148	155
100	115	152	152	162	162	168	168	175	180
125	141	182	182	192	192	195	195	210	217
150	169	207	207	218	218	225	225	247	257
175	195	237	237	248	248	255	267	277	287
200	220	262	262	273	273	285	292	309	324
250	274	318	318	328	330	342	353	364	391
300	325	373	373	378	385	402	418	424	458
350	368	423	423	438	445	458	475	486	512
400	420	473	473	490	497	515	547	543	627
450	470	528	528	540	557	565	572	588	704
500	520	578	578	595	618	625	628	657	813
600	620	680	680	695	735	730	745	764	950
700	720	785	785	810	805	830	850	879	
800	820	890	890	915	910	940	970	988	
900	920	990	990	1015	1010	1040	1080	1108	
1000	1020	1090	1090	1120	1125	1150	1190	1220	